

froling

Operating instructions

Control Panel RBG 3200

Core module version 50.04 - Build 05.20



Translation of original German version of operating instructions for operators.

Read and follow all instructions and safety instructions.
All errors and omissions excepted.

CE

B0640522_en | Edition 09/11/2022

1	General	4
1.1	About these instructions	4
1.2	Safety information	4
2	Installing the RBG 3200	5
2.1	Connecting the bus cable	5
2.2	Setting end jumpers	5
2.3	Setting the module address	6
2.4	Initial startup	7
3	Overview of the basic functions	8
3.1	Control keys and display	8
3.1.1	Navigation keys	8
3.1.2	Status LED	8
3.1.3	Graphic display	9
3.2	Function keys	10
3.2.1	Info key	10
3.2.2	Service program key	11
3.2.3	DHW tank program key	11
3.2.4	Party program key	12
3.2.5	Setback program key	13
4	Operation	14
4.1	Setting parameters	14
4.2	Setting times	14
4.2.1	Deleting a time window	15
5	Parameters overview	16
5.1	Heating	16
5.1.1	Heating - Status	16
5.1.2	Heating - Temperatures	17
5.1.3	Heating - Times	18
5.2	Water	18
5.2.1	Water - Status	18
5.2.2	Water - Temperatures	19
5.2.3	Water - Times	19
5.3	Solar	19
5.3.1	Solar - Status	19
5.3.2	Solar - Temperatures	21
5.4	Buffer tank	22
5.4.1	Buffer tank - Status	22
5.4.2	Buffer tank - Temperatures	22
5.5	Boiler 2	23
5.5.1	Boiler 2 - Status	23
5.5.2	Boiler 2 - Temperatures	23
5.6	Difference regulator	24
5.6.1	Difference regulator - Status	24
5.7	Circulation pump	25
5.7.1	Circulation pump - Status	25
5.7.2	Circulation pump - Temperatures	25
5.7.3	Circulation pump - Times	25
5.8	System	26
5.8.1	System - Current values	26
5.8.2	System - Error	26
5.8.3	System - Basic display parameters	26
5.8.4	System - Language	27

5.8.5	System - Current Date	27
5.8.6	System - Current Time	27
5.8.7	System - Current User Level.....	28
6	Troubleshooting	29
6.1	Procedure for fault messages	29

1 General

1.1 About these instructions

Please read and follow the operating instructions, in particular the safety information contained therein. Keep them available next to the boiler.

These operating instructions include important information about operation, electrical connection and troubleshooting. The parameters shown depend on the set boiler type and the system configuration!

The constant further development of our products means that there may be minor differences from the pictures and content. If you discover any errors, please let us know: doku@froeling.com.

1.2 Safety information

DANGER




When working on electrical components:

Risk of electrocution!

When work is carried out on electrical components:

- Always have work carried out by a qualified electrician
- Observe the applicable standards and regulations
 - ↳ Work must not be carried out on electrical components by unauthorised persons


2 Installing the RBG 3200



- Fit the holding frame as shown at the desired position in the room using the anchors and screws provided
 - ↳ The large grommet must be on the left!
 - ↳ It is recommended to install the device above a flush-mounted socket so that there is plenty of space to stow away the bus cable.

2.1 Connecting the bus cable


For the bus connections between the individual modules, cable type **LIYCY paired 2x2x0.5** should be used. The connection to the 5-pin plugs should be carried out according to the following diagram:



2.2 Setting end jumpers

NOTICE! To ensure smooth running of the bus system, the jumper must be set on the first and last module.

When using a bus repeater, the two galvanically separated sub-networks must be considered separately. The jumpers for each network must be set on the first and last module.



If the contacts at the base of the end jumper are not bridged (image left), it is referred to as “not set”. In this case there is no bus termination. If the contacts are closed (image right), the end jumper is set and the bus connection is terminated.

2.3 Setting the module address

You must set the required order with the module addresses for the RBG 3200 (display module). The standard boiler comes with a display module (boiler display) with the address 0 (except S3 Turbo with S-Tronic controller). If you, therefore, install an additional display module, set it to address 1 so that the standard hydraulic system settings do not need to be reconfigured. Set all further RBG 3200s module addresses in ascending order (2 to 7).

Important! Only set the module address when the device is disconnected from the power supply!



2.4 Initial startup

NOTICE


You should have the initial startup carried out by the authorised heating engineer from Froling customer services.

Once you have connected the device to the power supply and switched on the main switch, the start logo will appear and the control will perform a system check. After the system check the basic display will appear. The default basic display provides information about the two main parameters, however it can be customised to the user's individual requirements.

➔ ["System - Basic display parameters" \[▶ 26\]](#)

3 Overview of the basic functions

3.1 Control keys and display



3.1.1 Navigation keys

The navigation keys are used to move within the menu and to change parameter values.


Key	Function for	
 UP arrow	navigation:	move up a menu level
	parameter change:	depending on how long the key is pressed: - short: increase value - long: increase value in increments of 10 - long (>10 secs): increase value in increments of 100
 DOWN arrow	navigation:	move down a menu level
	parameter change:	depending on how long the key is pressed: - short: reduce value - long: reduce value in increments of 10 - long (>10 secs): reduce value in increments of 100
 Enter key	navigation:	go to selected menu
	parameter change:	release the parameter for editing, or save parameter value after changing
 Back key	navigation:	go back up a menu level
	parameter change:	depending on how long the key is pressed: - short: do not save parameter - long: back to basic display without saving

3.1.2 Status LED

The status LED shows the operating status of the system:


- GREEN flashing (interval: 5 sec OFF, 1 sec ON):
- GREEN constant: **BOILER SWITCHED ON**
- ORANGE flashing: **WARNING**
- RED flashing: **FAULT**

3.1.3 Graphic display



Ref.	Description	
1	Shows operating status or menu name	
2	Shows the current time	
3	Displays the main values in the basic display (adjustable) menu contents, parameters and info texts	
4	Status toolbar	
5	Displayed when a fault is pending. Press the info key to display texts describing the fault and the solution	
6	Shows the storage tank loading status (storage tank is optional)	
7	Indicates that an info text is displayed. Info texts are also identified by a frame	
8	Shows which function is active ➔ "Function keys" [▶ 10]	
9	Shows that the DHW tank loading pump is active	Only shown in the basic display !
10	Shows that the storage tank loading pump is active	
11	Shows that the heating circuit pump of the 2nd heating circuit is active	
12	Shows that the heating circuit pump of the 1st heating circuit is active	

In the service technician user level, the function of the relevant components is also shown in the individual status menu by the corresponding status display:



Ref.	Description	
A	Shows whether the storage tank (or oil boiler) is hot enough for hot water preparation	Only for service technicians in the status menu
B	Shown when the DHW tank or return temperature control pump is active	
C	Shown when the heating circuit or storage tank loading pump is active	
D	Shows the status of the heating circuit mixer	

3.2 Function keys

The function keys of the key control partially have dual functions. Short or long pressing of the keys can access different functions (see below):

- short keystroke < 1 sec
- long keystroke > 4 sec

3.2.1 Info key


Keystroke		Function
	short	Shows plain text information about the menu items or fault messages
	long	Choose language: Deutsch, English, Francais, Italiano, Slovenski, Cesky, Polski, Svenska, Espanol, Magyar, Suomi, Dansk, Nederlands, Russian, Serbian

The info key can be pressed at any time and always shows information about the current menu item or the current fault message. Fault messages take highest priority.

Info key in normal mode:









In normal operation (without pending fault messages) the info key can be pressed to display information or an explanation for every menu item or parameter.

The info text is also identified by the frame and the info symbol in the status line.

Info key when there is a pending fault:







If a fault has been acknowledged after arising, but not resolved, this is shown by a warning symbol at the bottom right on the status line.

Pressing the info key calls up the information on the currently pending fault message again.

Procedure for troubleshooting:

[➡ "Troubleshooting" \[▶ 29\]](#)



3.2.2 Service program key

Keystroke		Function	
	Short	Chimney sweep	Only with boiler display! NOTICE! See operating instructions for boiler controller!
	Long	Service mode	Only with boiler display! NOTICE! See operating instructions for boiler controller!


3.2.3 DHW tank program key

Keystroke		Function
	short	Single manual loading of domestic hot water. The function is indicated during DHW tank loading by the tap symbol in the status line. After loading, the mode that was previously set becomes active again.
	long	Only with boiler display! IMPORTANT! See operating instructions for boiler controller!

3.2.4 Party program key

Keystroke	Function
	<p>Short</p>  <p>The allocated heating circuit is switched to daytime mode after an optional change of the room temperature setpoint until the end of the next heating phase or until automatic mode is activated.</p>
	<p>Long</p>  <p>The allocated heating circuit and the domestic water heating for the allocated DHW are activated for 6 hours.</p>

Activate party mode





After the Party Mode key is pressed, an entry field to optionally change the “Room temperature setpoint” appears on the display. If no other key is pressed, daytime mode starts until the end of the next heating phase or until the automatic mode is activated for the allocated heating circuit with the preset room temperature.


After the Enter key has been pressed, the “Room temperature setpoint” can be adjusted with the UP arrow key and DOWN arrow key.

After confirmation by pressing the Enter key, the illustrated info text is displayed and daytime mode is activated for the allocated heating circuit until the end of the set time or until automatic mode is activated.

3.2.5 Setback program key

Keystroke		Function	
	Short		After an optional change to the setback temperature the heating circuit controller remains in setback mode until the start of the next heating time or until activation of another mode.
	Long		The room temperature is reduced to the preset setback temperature until another mode is activated.

Activate setback mode




After the Setback Mode key is pressed, an entry field to optionally change the “Setback room temperature setpoint” appears on the display. If no other key is pressed, setback mode starts until the end of the next heating phase or until the automatic mode is activated for the allocated heating circuit with the preset “setback room temperature setpoint”.

After the Enter key has been pressed, the “Setback room temperature setpoint” can be adjusted with the UP arrow key and DOWN arrow key.

After confirmation by pressing the Enter key, the illustrated info text is displayed and setback mode is activated for the allocated heating circuit until the end of the set time or until automatic mode is activated.

4 Operation

4.1 Setting parameters




4.2 Setting times


The desired time window for the component can be set in the "Times" submenu in the individual menus of the heating components (heating circuits, DHW tanks ...). The structure of the time menu and the procedure for changing the times are always the same.

Example - Setting times for heating circuit 01:

In the "Heating" menu -> "Times":



... In the "Change program" menu:



4.2.1 Deleting a time window

To delete a time window, the end time of the desired time window must be put to 24:00. If you press the up arrow key repeatedly, the time disappears and is replaced by dashes. Then carry out the same process with the start time. After the enter key has been pressed repeatedly, the changes are adopted and it returns to the previous menu.

5 Parameters overview

5.1 Heating

5.1.1 Heating - Status



Heating circuit mode	
Display and setting the heating circuit mode:	
	Auto: Automatic: heating phases according to the set heating times
	Extra heating: The heating circuit is regulated to the set room temperature with no time limitation. To cancel this function, activate another mode/function
	Setback: Setback mode; the current or next heating phase is ignored
	Continuous setback mode: Heating circuit remains in setback mode until another mode is activated
	Party: Party mode; the current or next setback phase is ignored
	OFF: Switched off; heating circuit deactivated, only frost protection!
Actual flow temperature	
Display of the current flow temperature.	
Flow temperature setpoint	
Display of the calculated flow temperature setpoint.	
Room temperature	
Prerequisite: Heating circuit used in conjunction with remote control	
Display of the current room temperature.	
Outside air temperature	
Display of the current outside air temperature.	

5.1.2 Heating - Temperatures

Basic display → Heating → Heating circuit 1 → Temperatures

Desired room temperature during heating mode

Prerequisite: Heating circuit used in conjunction with remote control

Room temperature which is regulated during the set heating times.

Desired room temperature during setback mode

Prerequisite: Heating circuit used in conjunction with remote control


Room temperature which is regulated outside of the set heating times.

Flow temperature SP at outside air temperature of +10°C

First setting point for definition of heating curve.

Flow temperature SP at outside air temperature of -10°C

Second setting point for definition of heating curve.



Reduction of flow temperature in setback mode

The flow temperature is reduced by this value during setback mode.

External temperature, at which heating circuit pump switches off in heating mode

If the outside air temperature exceeds this value during heating, the heating circuit pumps and mixing valve are deactivated.

External temperature, at which heating circuit pump switches off in setback mode

If the outside air temperature falls below this value in setback mode, the heating circuit pumps and mixing valve are activated.

Frost protection temperature

If the room temperature or the flow temperature is lower than the set value, the heating circuit pump will be switched on and the heating circuit mixer keeps to the maximum heating circuit flow temperature that is set.

<p>From which temperature at storage tank top should the overheating protection be activated?</p> <p>If the temperature at top storage tank exceeds the set value, the heating circuit is activated regardless of mode (boiler, remote control) and set heating times. The flow temperature is controlled to the value set in the parameter "Flow temperature SP at outside air temperature of -10°C". The function will remain active until the value falls below 2°C.</p> <p>Recommendation: The overheating protection should be assigned to a high temperature heating circuit (e.g. radiators).</p>
<p>Deviation of room temperature sensor</p> <p>If a deviation of the room temperature is determined from the evaluated value to the displayed value, the evaluation of the room temperature sensor can be adjusted with this parameter. The temperature measured by the sensor is increased (positive value) or reduced (negative value) by the pre-set value.</p>

5.1.3 Heating - Times



[↻ "Setting times" ▶ 14\]](#)


5.2 Water

5.2.1 Water - Status



<p>DHW tank top temperature</p> <p>Current temperature of the DHW tank. If the time window for DHW tank loading is reached and the temperature falls below the value set under parameter "Reload if DHW tank temperature is below", the DHW tank will be loaded. The DHW tank is loaded either until the time window has elapsed or the temperature set under "Desired DHW tank temperature" has been reached.</p>
<p>DHW tank bottom temperature</p> <p>Prerequisite: Solar panel system is regulated by Froling!</p> <p>Current temperature in the area of the reference sensor of the solar panel system.</p>
<p>DHW tank pump control</p> <p>Specifies the speed of the DHW tank pump as a percentage of maximum speed.</p>

5.2.2 Water - Temperatures



Set DHW temperature

When this DHW temperature is reached, DHW tank loading is stopped.

Reload if DHW tank temperature is below

If the DHW tank temperature falls below the value set here, the time window is active and the loading source (boiler or buffer tank) indicates the set loading increase, and the DHW tank loading is started.

5.2.3 Water - Times



➔ "Setting times" [▶ 14]

5.3 Solar

5.3.1 Solar - Status



Collector temperature

Display of the current temperature at the solar collector.

Top storage tank solar sensor

Display of the current temperature at the solar reference sensor in the top part of the buffer tank.

Solar temperature buffer tank bottom


Display of the current temperature at the solar reference sensor in the lower part of the buffer tank.

Actual power from solar heat meter [kW]

Display of the current output which is generated by the solar collector. The calculation of the output is only performed either when a per litre output of the collector pump has been set or an external volume pulse transmitter is used. In order to perform the calculation more precisely, the use of a collector return sensor is recommended.

Flow through [l/h]
Prerequisite: External volume pulse transmitter installed Display of the water quantity currently being pumped through the solar collector.
Todays yield [kWh]
Display of the heat quantity that has been supplied by the solar panel system today.
Daily yield 1 ... 6 days ago [kWh]
Shows the historical progression of the solar panel system. The yields of the last 6 days are available.
Total yield [kWh]
Display of the heat quantity which has been supplied by the solar panel system since activation of the heat meter.
DHW tank bottom temperature
Current temperature in the area of the reference sensor of the solar panel system.
Heat exchanger sec. return temperature (line to buffer tank)
Prerequisite: Hydraulic system 12 or 13 Current temperature at heat exchanger flow on the secondary side.
Collector pump runtime
Display of the total runtime of the collector pump.
Collector pump control
Display of the current speed of the collector pump as a percentage of maximum speed.
Pump between heat exchanger and buffer tank
Prerequisite: Hydraulic system 12 or 13 Display of the current speed of the pump between heat exchanger and buffer tank.
Pump between heat exchanger and DHW tank
Prerequisite: Hydraulic system 12 Display of the current speed of the pump between heat exchanger and DHW tank.
Diverter valve for top/bottom coils
Prerequisite: Hydraulic system 12 or 13 Current control of the isolating valve on the solar side. <ul style="list-style-type: none"> ▪ 0% ... bottom buffer tank ▪ 100% ... top buffer tank
Outfeed: 80°C / RL: 50°C P: 0.0 kW / DFL: 0 Today: 0 kWh Total: 0 kWh
<ul style="list-style-type: none"> ▪ OUTFEED: Current collector flow temperature ▪ Return: Current collector return feed temperature ▪ P: Current output which is generated by the solar collector ▪ DFL: Current flow rate of solar collector ▪ Today: Heat quantity that has been produced by the solar panel system today ▪ Total: Heat quantity that has been produced since activation of the solar panel system

5.3.2 Solar - Temperatures



Boiler target temperature during solar charging

Up to this temperature the DHW tank is heated by the solar system. If the solar panel system is equipped with an isolating valve for switching between DHW tank and buffer solar coil, then this parameter is responsible for switching between both of these solar coils.

Temp differential to start collector pump

The collector pump activates when the collector temperature exceeds the reference temperature in the DHW tank or buffer tank by this value.

Temp difference to stop collector pump

The collector pump switches off when the difference between the collector temperature and reference temperature in the DHW tank or buffer tank is lower than this value.

Maximum buffer tank bottom temperature during solar charging

Prerequisite: Hydraulic system 12 or 13

If the sensor for the solar reference temperature in the buffer tank exceeds the specified value, the collector pump is switched off.

Collector/pump protection from a collector temp.

If the measured value of the solar collector sensor exceeds the set value, the solar collector must cool down by 20°C within 15 minutes, otherwise the solar collector pump stops in order to protect the pump.

5.4 Buffer tank

5.4.1 Buffer tank - Status



Buffer tank top temperature
Display of the current temperature in the top part of the buffer tank.
Storage tank temperature sensor 2 ... 7
Prerequisite: Multi-sensor management with 3 – 8 sensors
Displays the current temperature at the respective sensor position at the storage tank. All of the configured sensors are used to calculate the storage tank charge status.
Buffer tank bottom temperature
Display of the current temperature in the lower part of the buffer tank.
Buffer tank pump control
Display of the current speed of the buffer loading pump.
Storage tank charge
Display of the current storage tank charge.


5.4.2 Buffer tank - Temperatures



Heating circuit release from following buffer tank temperature
Temperature value which must be reached to release the heating circuit pumps in the top part of the buffer tank.
NOTICE! This parameter applies for all available heating circuits!

5.5 Boiler 2

5.5.1 Boiler 2 - Status



Temperature of secondary boiler

Display of the current boiler temperature of the secondary boiler.

Burner relay status

Shows the current status of the burner relay:

- **0:** Secondary boiler not active
- **1:** Secondary boiler active

Standby boiler pump

Prerequisite: "Switch valve installed" parameter set to "NO"

Display of the current pump control for the standby boiler.

Standby boiler switch valve

Prerequisite: "Switch valve installed" parameter set to "YES"

Display of the current switch valve control of the standby boiler.

Manual start of secondary boiler (only when ID fan is switched off)

- **OFF:** Secondary boiler is controlled according to the program that is set
- **ON:** Secondary boiler is activated immediately

NOTICE! Burner blockage noted.

5.5.2 Boiler 2 - Temperatures



Secondary boiler start delay

If there is a requirement from the heating circuit or DHW tank and the buffer tank or boiler has insufficient temperature, the secondary boiler starts after the specified delay time set here.

Disable startup delay in case of fault?

Indicates whether the startup delay is ignored in the event of a boiler fault and whether the standby boiler is activated immediately on request.

Deactivate startup delay when boiler is switched off?

Indicates whether the startup delay is ignored when the boiler is switched off and whether the standby boiler is activated immediately on request.

Start standby boiler only after storage tank top
Standby boiler enabled after temperature decreases below minimum temperature on top storage tank. No consumers are taken into consideration.
Secondary boiler minimum runtime
If the secondary boiler is started, it will run for at least the length of time set here.
No heat pump operation when outside air temperature less than
Prerequisite: Heat pump as standby boiler The heat pump stops working below the set temperature. This avoids operation with high energy consumption when the temperature outside is cold.
Maximum outfeed temperature for heat pump operation
Prerequisite: Heat pump as standby boiler If a flow temperature higher than the set value is required, the main boiler takes over.
Main boiler minimum runtime
Prerequisite: Heat pump as standby boiler If the main boiler is in operation, it only shuts down after the minimum runtime of the main boiler if the criteria for heat pump operation are fulfilled. This should prevent excessively short runtimes of the main boiler.
Temperature difference between secondary boiler and buffer tank
Temperature difference between secondary boiler and upper temperature in layered tank to activate the loading pump of the secondary boiler.

5.6 Difference regulator

5.6.1 Difference regulator - Status



Heat source temperature
Display of the current heat source temperature of the differential controller (e.g. tiled stove with water pocket, ...).
Heat sink sensor
Display of the current temperature of the heat sink for the differential controller (e.g. layered tank, etc.).
Pump speed
Specifies the current speed of the differential controller pump.

5.7 Circulation pump

5.7.1 Circulation pump - Status



Return temperature in circulation line

Display of the current temperature at the return feed sensor of the circulation line.

NOTICE! If the parameter "Return sensor present" is set to "NO", 0°C is permanently displayed.


Flow switch on the domestic hot water line

- 0: Flow switch detects no flow rate.
- 1: Flow switch detects flow rate.

Speed of the circulation pump

Specifies the current speed of the circulation pump.

5.7.2 Circulation pump - Temperatures



Switch off the pump at what return temperature in the circulation line

If the set temperature at the return circulation line is reached, the circulation pump will be deactivated.

NOTICE! Parameter only relevant when using a return feed sensor in the circulation line!


5.7.3 Circulation pump - Times



➔ "Setting times" [▶ 14]

5.8 System

5.8.1 System - Current values



Display of the current value for the relevant parameter. The parameters displayed depend on the boiler configuration!


5.8.2 System - Error

Error - Error display



Display of the current fault messages. In addition, you can also invoke time information here, such as when the fault occurred, when the fault was acknowledged and when the fault was cleared.

5.8.3 System - Basic display parameters



You can individually adjust how the two items are shown in the basic display, and for each item you can choose from several parameters: e.g. boiler, flue gas, external, room, DHW tank, storage tank top, storage tank bottom, storage tank graph, etc.

Position 1	Boiler	Selected
Position 2	Flue gas	Selected
<p>Off 10:27 ↓ Boiler 26 ° ↓ Flue gas 26 ° ⌚ 📄</p>	<p>Heating 13:52 🏠 77 ° AT 5 ° --- KT 30 ° 72 ° BT 36 ° 🔧 ⌚ 📄</p>	

If the “storage tank graph” is selected, the temperatures of the top, middle (if available) and bottom storage tanks will be displayed next to the graph. In addition, further, fixed predefined values will be displayed:

OT ... Outside temperature
 BT ... Boiler temperature
 RT ... Room temperature (on room console BT is replaced by RT)
 DT ... DHW tank temperature (if available)

5.8.4 System - Language



Language - Sprache - Langue - Lingua - Jezik

- Deutsch, English, Francais, Italiano, Slovenski, Cesky, Polski, Svenska, Espanol, Magyar, Suomi, Dansk, Nederlands, Русский, Serbian

5.8.5 System - Current Date



Current Date

Display and setting of current date.


5.8.6 System - Current Time



Current Time

Display and setting the current time.

5.8.7 System - Current User Level

**Child lock (Code "0")**

At "Child lock" level, only the "Status" menu appears. It is not possible to change parameters at this level.

Customer (Code "1")

Standard user level for normal operation of the display. All customer-specific parameters are displayed and can be changed.

Installer / Service

Releases parameters to adjust the controller to the system components (if configured).

6 Troubleshooting


The term "fault" is a collective term for warnings, errors and alarms. The boiler reacts differently to the three types of message:

WARNING	In case of warnings the status LED flashes orange and the boiler initially continues controlled operation.
ERROR	In case of errors, the status LED flashes red, the boiler follows shutdown procedure and remains in operating status " ", until the error is resolved. After troubleshooting, the boiler switches back to the operating status "".
ALARM	An alarm triggers a system emergency stop. The status LED flashes red, the boiler switches off immediately and the heating circuit controller and pumps remain active.

6.1 Procedure for fault messages

When a fault occurs:

- The status LED flashes with a red or orange light
- The display shows the current fault message and the warning symbol in the status line



Manufacturer's address

Fröling Heizkessel- und Behälterbau GesmbH

Industriestraße 12
A-4710 Grieskirchen
+43 (0) 7248 606 0
info@froeling.com

Zweigniederlassung Aschheim

Max-Planck-Straße 6
85609 Aschheim
+49 (0) 89 927 926 0
info@froeling.com

Froling srl

Via J. Ressel 2H
I-39100 Bolzano (BZ)
+39 (0) 471 060460
info@froeling.it

Froling SARL

1, rue Kellermann
F-67450 Mundolsheim
+33 (0) 388 193 269
froling@froeling.com

Installer's address

Stamp

Froling customer services

Austria
Germany
Worldwide

0043 (0) 7248 606 7000
0049 (0) 89 927 926 400
0043 (0) 7248 606 0



www.froeling.com

froling 